



**CLASSIC MULTI-SLOT BASE  
CLASSIC ALUMINUM BASE  
CLASSIC ALUMINUM BASE PAIR  
CLASSIC MUZZLELOADER BASE  
GRANDSLAM STEEL DOVETAIL BASES  
TACTICAL PICATINNY EXTENDED MULTI-SLOT BASES**

**⚠ WARNING: UNLOAD FIREARMS BEFORE INSTALLATION TO PREVENT SHOOTING ACCIDENTS.**

**ASSEMBLY INSTRUCTIONS:**

**1. USE A PADDED VISE TO HOLD FIREARM STEADY AND REMOVE FILLER SCREWS FROM RECEIVER.**

**CLEAN FIREARM RECEIVER, RECEIVER BASE HOLES AND ALL MOUNT PARTS THOROUGHLY.**

**2. PLACE THE BASE(S) ON THE RECEIVER AND ALIGN HOLES.**

**INSERT MOUNT BASE SCREWS\*.**

**TIGHTEN MIDDLE SCREW(S) FIRST AND THEN END SCREWS, BUT NOT FULLY TIGHTENED.**

**GO OVER THE ENTIRE SYSTEM, TIGHTENING ALL SCREWS AS TIGHT AS YOU CAN.**

**DO NOT EXERT ENOUGH TORQUE TO SNAP THE SCREWS.**

**NOTE: MANY GUNSMITHS ALSO APPLY A SMALL DROP OF THREAD ADHESIVE TO THE BASE SCREWS. (DO NOT ALLOW ADHESIVE TO GET INTO THE ACTION).**

**3. REFER TO RING AND SCOPE MANUFACTURE RECOMMENDED MOUNTING INSTRUCTIONS TO FINISH SCOPE INSTALLATION.**

**\*SOME FIREARMS REQUIRE THE USE OF TWO DIFFERENT LENGTH BASE SCREWS. IF A BASE SHIPS WITH TWO DIFFERENT LENGTH SCREWS TYPICALLY THE SHORTER SCREWS ARE USED IN THE FRONT OF THE RECEIVER.**

[https://www.weaveroptics.com/on/demandware.static/-/Library-Sites-HuntShootAccessoriesSharedLibrary/default/dwb30465c4/productPdfFiles/weaverPdf/weaver\\_torque\\_specs.pdf](https://www.weaveroptics.com/on/demandware.static/-/Library-Sites-HuntShootAccessoriesSharedLibrary/default/dwb30465c4/productPdfFiles/weaverPdf/weaver_torque_specs.pdf)